QPCTMR 09/07

Physical Connection Permit No.:	WPC
--	-----



NEW JERSEY DEPARTMENT OF ENVIRONMENTAL PROTECTION Quarterly Physical Connection Test & Maintenance Report

04/01-06/30 07	Quarter 3 rd Quar 7/01-09/30 10/01-12 ate of test//	2/31 01/01-03/31	approved valve. and Local Admin and inspection poshall be kept at the	It is to be mailed to nistrative Authority erformed by a Certif he facility and be ex	bleted for each test of each the Supplier of Water within 5 days of each test fied Tester. These forms hibited upon request, and cal Connection Renewal	
To:			From: (Name of Permit Holder)			
The backflow pr	evention device iden	ntified below has bee	en tested and inspec	eted as required b	y N.J.A.C. 7:10-10.6	
1		ertified to be in com			•	
]	Description of Valve	2	Location of Valve			
Manufacturer:		RPZ DCVA		·		
						
Comments and N	otations:					
	PRESSURE TEST	INTERNAL INSPECTION				
	I ILLUDUCIAL ILLUI			DOUBLE CHECK VALVE		
		SURE ZONE ASSEN	MBLY		CK VALVE	
	REDUCED PRESS DOUBLE CHECK	SURE ZONE ASSEM VALVE		ASSEMBLY		
X 15	REDUCED PRESS DOUBLE CHECK 1st Check	SURE ZONE ASSEN VALVE 2 nd Check	Relief Valve	ASSEMBLY 1 st Check	2 nd Check	
Initial Test	REDUCED PRESS DOUBLE CHECK 1 st Check Closed Tight	SURE ZONE ASSEM VALVE 2 nd Check Closed Tight	Relief Valve Opened at	ASSEMBLY		
	REDUCED PRESS DOUBLE CHECK 1 st Check Closed Tight at psid	SURE ZONE ASSEM VALVE 2 nd Check Closed Tight psid	Relief Valve	ASSEMBLY 1 st Check	2 nd Check	
Initial Test Passed	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight at psid Leaked Leaked	SURE ZONE ASSEMENT OF THE PROPERTY OF THE PROP	Relief Valve Opened at psid	ASSEMBLY 1st Check OK	2 nd Check OK	
	REDUCED PRESS DOUBLE CHECK 1 st Check Closed Tight at psid	SURE ZONE ASSEMENT OF THE PROPERTY OF THE PROP	Relief Valve Opened at	ASSEMBLY 1 st Check	2 nd Check	
Passed Failed Repairs &	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight at psid Leaked No. 2 Shut-off Valve	SURE ZONE ASSEMANCE VALVE 2nd Check Closed Tight psid at psid Leaked ce Closed Tight ce Closed Tight	Relief Valve Opened at psid	ASSEMBLY 1st Check OK	2 nd Check OK	
Passed Failed Repairs & Materials Used	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight at psid Leaked No. 2 Shut-off Valv Leaked Leaked	SURE ZONE ASSEMANCE VALVE 2nd Check Closed Tight psid at psid Leaked becomes closed Tight By-pass Used	Relief Valve Opened at psid Did Not Open	ASSEMBLY 1st Check OK Failed	2 nd Check OK Failed	
Passed	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked Closed Tight Closed Tight	SURE ZONE ASSEMANCE VALVE 2nd Check Closed Tight psid Leaked see Closed Tight see Closed Tight see Closed Tight contact see Closed Tight see Close	Relief Valve Opened at psid Did Not Open Opened at	ASSEMBLY 1st Check OK	2 nd Check OK	
Passed Failed Repairs & Materials Used	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight at psid Leaked No. 2 Shut-off Valv Leaked Leaked	SURE ZONE ASSEMANCE VALVE 2nd Check Closed Tight psid at psid Leaked becomes closed Tight By-pass Used	Relief Valve Opened at psid Did Not Open	ASSEMBLY 1st Check OK Failed	2 nd Check OK Failed	
Passed Failed Repairs & Materials Used Test After Repair & Assembly	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked Shut-off Valv Leaked psid	SURE ZONE ASSEMANCE VALVE 2nd Check Closed Tight psid Leaked become as	Relief Valve Opened at psid Did Not Open Opened at psid	ASSEMBLY 1st Check OK Failed OK OK	2 nd Check OK Failed OK OK OK	
Passed Failed Repairs & Materials Used Test After Repair & Assembly The Results SI	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked Closed Tight Closed Tight	SURE ZONE ASSEMENT VALVE 2nd Check Closed Tight psid Leaked By-pass Used Closed Tight psid By-pass Used Closed Tight psid Closed Tight psid	Relief Valve Opened at psid Did Not Open Opened at psid Opened at psid	ASSEMBLY 1st Check OK Failed OK OK esses to test and in	2 nd Check OK Failed OK OK OK	
Passed Failed Repairs & Materials Used Test After Repair & Assembly The Results SI Certified Testers N	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked psid Closed Tight psid Closed Tight psid	SURE ZONE ASSEMENT VALVE 2 nd Check Closed Tight psid Leaked Psid Psid	Relief Valve Opened at psid Did Not Open Opened at psid Vitne	ASSEMBLY 1st Check OK OK OK OK Title:	2 nd Check OK Failed OK OK OK OK OK OK OK OK	
Passed Failed Repairs & Materials Used Test After Repair & Assembly The Results SI Certified Testers N	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked psid Closed Tight psid Closed Tight psid	SURE ZONE ASSEMENT VALVE 2 nd Check Closed Tight psid Leaked Psid Psid	Relief Valve Opened at psid Did Not Open Opened at psid Vitne	ASSEMBLY 1st Check OK OK OK OK Title:	2 nd Check OK Failed OK OK	
Passed Failed Repairs & Materials Used Test After Repair & Assembly The Results SI Certified Testers N Certified Testers S	REDUCED PRESS DOUBLE CHECK 1st Check Closed Tight psid Leaked No. 2 Shut-off Valv Leaked psid Closed Tight psid Closed Tight psid	SURE ZONE ASSEMENT VALVE 2nd Check Closed Tight psid Leaked By-pass Used Closed Tight psid Losed Tight psid Leaked for Closed Tight psid Leaked for Closed Tight psid Closed Tight psid Leaked psid Leaked for Closed Tight psid Leaked psid Leaked for Closed Tight psid Leaked for	Relief Valve Opened at psid Did Not Open Opened at psid Vitne	ASSEMBLY 1 st Check OK Failed OK Title:	2 nd Check OK Failed OK OK OK OK OK OK OK OK	

Physical Connection Permit No.: Physical Connection Permit No.: ____-WPC_____

<u>Test Procedure for Backflow Preventer Valve Assembly</u> Set Up Procedure for Testing

- 1. Verify that upstream shut-off valve No. 1 is open, and there is water pressure. Close downstream shut-off valve No. 2. <u>Note for Reduced Pressure Zone Valves:</u> A discharge from the relief port indicates a leaking No. 1 check valve. If there is no discharge No. 1 check can be assumed to be holding tight.
- 2. Flush test cocks Nos. 2, 3 & 4.
- 3. Close Test Kit high valve (A) and low valve (B), leave vent valve (C) open.

Reduced Pressure Zone Valve Assembly Test

A) Test the **first check valve** for tightness at a minimum of 5 PSID of static pressure:

- 1. Connect high-pressure hose to test cock #2.
- 2. Connect low-pressure hose to test cock #3.
- 3. Open test cocks #2 & #3.
- 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
- 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) Slowly.
- 6. Observe stable differential pressure on gauge and record on test form. (Must be 5 PSID Minimum)

B) Test the **second check valve** for tightness against backpressure:

- 1. Connect vent hose to test cock #4.
- 2. Open test cock #4.
- 3. Open test kit high valve (A)... Slowly.
- Observe gauge and record on test form. Second check is tight if differential pressure drops slightly and holds steady. If pressure continues to drop until relief port discharges second check is leaking.

C) Test No. 2 shut-off valve for tightness:

- 1. Close test cock #2.
- 2. Observe gauge, if #2 shut-off valve is tight gauge will hold steady, if leaking the differential pressure will fall. Record result on form.

<u>Note:</u> If No. 2 shut-off valve is leaking tests **A & B are invalid**; since the valve is not in a static condition. Another shut-off valve downstream or a temporary by-pass from test cock #1 to test cock #4 must be utilized.

D) Test the operation of the **differential pressure relief valve:** Relief valve must open at a minimum of 2PSID below inlet.

- 1. Open test cock #2, test kit high valve (A) shall remain open and close test kit vent valve (C).
- 2. **Slowly** open the test kit low valve (B) until the differential pressure begins to fall... **Slowly.**
- 3. Observe the relief valve port for the first discharge of water and record the pressure differential on the gauge at this point on the form.

Double Check Valve Assembly Test

- A) Test the **first check valve** for a minimum of 1 PSID of static pressure drop:
 - 1. Connect high-pressure hose to test cock #2.
 - 2. Connect low-pressure hose to test cock #3.
 - 3. Open test cocks #2 & #3.
 - 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
 - 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) **Slowly**.
 - 6. Observe stable differential pressure on gauge and record on test form. (Must be 1 PSID Minimum)
- B) Test the **second check valve** for a minimum of 1 PSID static pressure drop: (close test cocks #2 & #3 and remove high & low-pressure hoses)
 - 1. Connect high-pressure hose to test cock #3.
 - 2. Connect low-pressure hose to test cock #4.
 - 3. Open test cocks #3 & #4.
 - 4. Open test kit high valve (A) and bleed air and water through vent hose... Close high valve (A).
 - 5. Open test kit low valve (B) and bleed air and water through vent hose... Close low valve (B) **Slowly**.
 - 6. Observe stable differential pressure on gauge and record on test form. (Must be 1 PSID Minimum)

C) Test No. 2 shut-off valve for tightness:

- 1. Repeat procedure for test A.
- 2. Connect vent hose to test cock #4.
- 3. Open test cock #4.
- 4. Open test kit high valve (A) **Slowly**.
- 5. Close test cock #2.
- 6. Observe gauge, if #2 shut-off valve is tight gauge will hold steady, if leaking the differential pressure will fall. Record result on form.

Note: If No. 2 shut-off valve is leaking tests **A & B are invalid**; since the valve is not in a static condition. Another shut-off valve downstream or a temporary by-pass from test cock #1 to test cock #4 must be utilized.

Physical Co	nnection Permit No.: Physical Connection Permit No	.:WPC	QPCTMR09/07